

Cleaning Instructions

Mix up cleaning solution in bucket 6:1 Ratio 6 parts Water: 1 part Exterior Deep cleaner

Example of mixture 60 oz. water to 10 oz. cleaner

Apply the cleaning solutions very wet and evenly and allow to soak in for 20 min. working into stained areas.

Wipe off all the raised contaminates with clean white cloth, Rinse off with clean water and allow to dry completely. Overnight dry is best. (Stubborn stains may require to repeat cleaning process again before moving forward)

Keep out of direct sunlight while applying a nice wet and even coat of IPE oil, being very generous on end grain sides and top. Allow application to evenly penetrate and soak in for 3 min. before wiping excess oil off. Be sure to wipe all oil off and not allow any pooling. Avoid rain for 24 hrs.

STEP 1: Clean – allow cleaner to soak 20 minutes

STEP 2: wipe off and rinse

STEP 3: Allow to dry completely

STEP 4: Apply oil generously and evenly -soak in 3 minutes.

STEP 5: Wipe off excess oil

STEP 6: Allow to dry 24 - 72 hrs. before putting back into service. (For best results allow to be out of service to cure for 3-5 days)

