



CARE AND MAINTENANCE – STAINLESS STEEL

#4 Brushed Finish (Satin) - this is the Standard Stainless-Steel finish for most appliances. This finish should be wiped clean with a mild soap and water solution, rinsed with clean water, and wiped with a clean, dry cloth for occasional smudges. For periodic maintenance, or to remove fingerprints, a stainless-steel cleaner should be used with a dry cloth. We recommend Magic Stainless Steel Cleaner.

Mirror Polished - this finish should be cleaned with a foam stainless steel cleaner, such as Magic Stainless-Steel Cleaner. Such foam cleaners can be used as often as necessary.

Here are some more tips on keeping your stainless clean and rust-free:

ALWAYS - clean stainless frequently with soap and water. Any cleaner safe for glass is usually safe for stainless.

NEVER - use coarse abrasives like sandpaper or steel wool on stainless. They may cause rusting.

NEVER - clean with mineral acids or bleaches.

NEVER - leave stainless in contact with iron, steel or other metals which cause contamination leading to rust or corrosion.